




Fusion Series: WEEPING WILLOW



Parts Needed:

- Nozzle base x 1
- .5 Nozzle Tip x 6
- .6 Nozzle Tip x 7
- 10° Elbow x 18
- Screw x 80
- Flow Control x 6
- Rubber Plug x 1
- 1x Flare Attachment (already installed)
- Bolt x 1

1. Assemble Nozzle Groups:

Group 1 (6 total)

Group 2 (6 total)

Group 3 (1 total)

2. Install Nozzles Groups to Base

Install 6x **Group 1** Nozzles on holes 7-12
 Install 6x **Group 2** Nozzles on holes 1-6

Use these holes so that nozzles point straight away from the center

For a Twister setup install **Group 1** using the rotated (45°) holes shown here

3. Install Flow Control

Insert 6x Flow Controls into the bottom of the Nozzle Base in holes 1-6, secure with 6x screws

4. Attach the Nozzle Base

For a Stationary Pattern:

Secure the Nozzle Base to the Unit using the bolt that goes through the center hole

Next secure the Center Nozzle (**Group 3**) to the center hole

For a Twister:
 Follow the instructions detailed on the "Installing Twister Module" page